

# REO PEGS

“NZ PAT APP 333028”

## FOUNDATIONS MADE EASY

### FOR TWO VERTICAL BAR CAGE OR TRENCHMESH

Drive Reo Pegs to height in footing prior to placing steel

Place Reo Pegs at 1000 CRS Max, in centre of footing with lugs facing towards direction of concrete pour

Clip reinforcing steel into lugs

Pour with concrete



### FOR TWO HORIZONTAL BAR OR FOUR BAR CAGE

Place cage in footing first

Drive Reo Pegs in to height beside cage at 1000 CRS Max and lift either bars or strips into appropriate lugs

